

USB Update

Download the update and connect the Brain cube without the colored cubes to your computer via USB.

ATTENTION: LAN must be switched off!

Put the update file (.tar.gz) into the home drive. Wait at least 30 seconds (transfer of data).

IMPORTANT: The file must end in .tar.gz.

Eject the home drive (remove safely).

ATTENTION: Do not simply pull the plug!

After ejecting, disconnect homee from your computer and connect the USB cable with the plug socket and connect homee (now with all cubes) to the power supply.

Your homee will now update itself. If the LED on the Brain cube lights green permanently, then the update is complete. This takes about 5 minutes.



LED
leuchtet

